


# CubeCell HTCC-AB01 Pinout Diagram



- 104

- VS\* : Solar input pin(5.5V~7V)
  - VEXT : External power supply (3.3V), control the switch of VEXT through GPIO(LOW-ON,HIGH-OFF)
  - VDD : 3.3V
  - VIN : 5V

