

R2

USER

R10

D3

D4

R12

R26

R3


R28

R6

R29

R27


F1




P1



RST




S1




P3

5V GND 13 14 47 48 4 5 0 21 19 17 26 20 18 16 15 7 6



U9



E2



R16

3V3GND V_e RX TX 33 34 35 36 37 38 39 40 41 42 45 46 3 2 1





P2

6 7 0 1 19

18 9 5 4

8

HT-DEV-ESP_V2



3

2

TX RX

