

Tip: BTB(P4) pins are labeled according to RC32 pins.

If using other devices, please refer to this document for pin correspondence.

https://wiki.heltec.org/docs/devices/open-source-hardware/radio_core_series/pin_comparison

