# Wireless Shell Pinout Diagram

Pins with this arrow are used by on-board OLED or LoRa, they must not be used for other purpose unless you know what you are doing!




**Notes:**

- Vext : External power supply (3.3V), control the switch of Vext through GPIO(LOW-ON,HIGH-OFF)
- ADC preamplifier GPIOs are 3.3V tolerant only